

Greetings, Retro Gamer!

Thank you for purchasing »Sam's Journey«, a brand-new scrolling platform game for the Commodore 64 home computer. The game features a cute little hero called Sam who finds himself on an unexpected journey through a strange and mystical world.

Your task is to guide Sam through more than a dozen exciting locations such as deep forests, hot deserts, and frozen mountains. Discover secret passages, find hidden coins, trophies, and gems, and avoid the dastardly creatures!



As well as basic moves such as run, jump, climb and swim, Sam can also pick up items, carry them around, and throw them at enemies! And with the power of special costumes, Sam can completely change his appearance and gain additional skills!

»Sam's Journey« is the first Knights of Bytes production after a break of more than a decade. We really appreciate your support and hope that you have as much fun playing this game as we had making it!

Chester Stefan Alex

Chester Kollschen, Stefan Gutsch and Alex Ney
Knights of Bytes



Getting Started

»Sam's Journey« requires a joystick connected to Port 2.

Note: To prevent hardware damage, please ensure your C64 computer is switched off before you attach or detach any hardware devices.

Cartridge Edition (PAL)

Switch off the C64 and plug the game cartridge into the expansion port with the label facing UP. Switch on the C64 and the game will start automatically.

Disk Edition (PAL/NTSC)

Before loading the game, please ensure that only one 1541 disk drive is connected to the C64.

NTSC Users: Plug your *Commodore REU* or *CMD REU* in the expansion port of your C64, or enable the REU emulation of your *1541 Ultimate* or *Turbo Chameleon 64*.

Switch on the C64 and the 1541 and insert Disk 1 of »Sam's Journey«. At the BASIC prompt, type **LOAD"*", 8** and hit the [RETURN] key. When the READY prompt appears, type **RUN** and hit the [RETURN] key. The game will start automatically.

Note: Please do not remove or flip the disk unless prompted to do so by the game.

Menu Navigation

In most situations, pressing [SPACE] will bring up a menu. You can navigate through the various menu options using the joystick and make your selection with the fire button.

Note: C64GS users can push the fire button on a joystick connected to Port 1 to bring up the menu.

Select a Game

»Sam's Journey« features three game slots to save your game. After the title sequence, you can select the game slot you wish to use:



For example, you could use game 1 for your own progress and allow family members or friends to use game 2 or game 3.

Once you've selected a game slot, you can see the current progress for that game, including overall score and time played.



Select **BACK** to pick a different game slot, or choose **PLAY** to start the game.

You can also select **MORE** to access further options: **RESET** will erase the selected game, while **COPY** allows you to copy the selected game to another game slot.

Note: Please use these options with care!

The Story

Whenever you start a new game, you'll be treated to an introductory sequence which sets the scene for the game. It begins one night in Sam's bedroom ...



After this short introduction, Sam will be dropped right into the action!

The Map



At the beginning of his journey, Sam finds himself at the bottom of a huge island. The path to the top of the island leads through **The Lowlands**, **The Midlands**, and **The Highlands**, each of which has its own map containing multiple levels. In total there are 30 levels for Sam to explore!

Starting a Level

To start playing, move Sam to a level access point using the joystick and push the fire button. When Sam stands on a level access point, you can see the level's name, its current status, and the best score achieved in that level so far.

A **black star** means that Sam hasn't completed the level yet. You must complete each level in sequence in order to progress to the next.



A **yellow star** indicates that Sam has completed the level at least once. You may replay any level as often as you like to grab any collectibles you may have missed and improve your score.



Saving the Game

Press [SPACE] to open the menu and select **SAVE** to save your current progress.



After saving, you can choose **CONTINUE** to resume the game, or select **QUIT** to end the game and return to the title sequence.

Tip: Even if you don't make any progress, save your game in order to keep track of the total time played!

Quitting the Game

Press [SPACE] to open the menu and select **QUIT** to exit the game and return to the title sequence.



Gameplay

Sam enters each level through the start door. Your objective is to guide Sam safely through the level and enter the flashing exit door (this will award you with a yellow star on the map screen).



Throughout his journey, Sam will encounter many creatures, most of which can be defeated by jumping on their heads. However, some creatures require a more powerful attack, while others may be completely immune to Sam's strikes!

Pause Menu

Press [SPACE] to pause the game and open the menu. Here you can resume playing, retry from the last checkpoint, restart the level, or return to the map.

Note: The menu also appears if Sam is killed by an enemy or falls into an abyss.

Controls

Sam is controlled using a joystick connected to Port 2.

Running

Use **left** or **right** to make Sam run in the desired direction. The longer you hold **left** or **right**, the faster Sam runs.



Jumping

Push **up** to make Sam jump.
The longer you hold **up**, the higher Sam jumps.



Push **up** and **left** or **right** to jump diagonally.
The faster Sam runs, the farther he jumps.
Use **left** or **right** to affect Sam's direction while in the air.



Hold **up** when landing on enemies, switches, or trampolines to jump off them.



Climbing


When Sam is standing above or in front of a climbable object:

Use **up** or **down** to make Sam grab the object and climb up or down.




When Sam is flying through the air:

Push **up** or **down** or **fire** to grab a climbable object.



When Sam is on a climbable object:

Push **up** or **down** to climb vertically and **left** or **right** to climb horizontally.



Hold **fire** and push either **up** to jump off or **down** to drop off.



When Sam is at the top of a climbable object:

Push **up** to jump off.



Swimming

When Sam is immersed in water:

Use **left** or **right** to make Sam swim into the desired direction.



Push **fire** to make Sam perform a swimming stroke and gain height.



Push **up** to jump out of the water when Sam is at the surface.



Note: Sam can hold his breath underwater indefinitely.

Peeking

When Sam is standing on the ground:

Push and hold **fire** until Sam turns blue.

While Sam is blue, use **up** and **down** to peek up and down.

Release **fire** to stop peeking.



Carrying Objects

Push **fire** in front of a movable object to make Sam pick it up.



Push **fire** to throw the object that Sam is currently carrying.



Push **fire** in combination with **left** or **right** to throw the object even farther.



Hold **down** and push **fire** to drop an object exactly where Sam is standing.



Entering Doors

When Sam is standing in front of a door:

Push **up** to enter the door.

Note: Sam must be carrying a key to enter locked doors.



Costumes

When Sam collects a costume, he will change appearance and gain that particular costume's super powers. Wearing a costume also allows Sam to take a hit from an enemy without dying.

Note: Sam will lose his current costume if he is hit by an enemy!



Ninja Sam

Ninja Sam can cling to walls and jump his way up narrow vertical passages.

Push **fire** to make Ninja Sam cling to a wall.


When Ninja Sam is clinging to a wall:

Hold **up** and **left** or **right** and push **fire** to jump off the wall diagonally.

Push and hold **down** to slide slowly down the wall.

Push **fire** to drop off.

Tip: Ninja skills come in useful on many different levels!



Pirate Sam

Pirate Sam can attack his enemies with his mighty cutlass!

Push **fire** to make Pirate Sam swing his cutlass.

Tip: The cutlass is also useful for opening chests!



Pitcher Sam




Pitcher Sam can throw rocks and chests with a powerful, targeted pitch. His baseball cleats also prevent him from sliding on ice!

If Pitcher Sam is carrying a rock or a chest:
Push and hold **down** to prepare a power pitch and activate the crosshairs.
Release **down** to cancel the power pitch.



Push **fire** to throw the object in the direction of the crosshairs.



Tip: A pitched object will collect any collectibles it hits along the way!

Disco Sam



Disco Sam's signature twist allows him to remain in the air for longer periods. He'll also inflict twice his usual damage if he collides with an enemy!

While Disco Sam is in the air:
Push and hold **fire** to make Disco Sam start his twisting move.



Use **left** or **right** to steer Disco Sam in the desired direction.



Tip: Disco Sam's cool shades can reveal secret passages—use the Peeking function to activate them!

Space Sam



Space Sam wears a jetpack that enables him to perform double-jumps, radically increasing his jumping height and distance.

After Space Sam has performed a jump:
Push and hold **fire** to fire a blast from Space Sam's jetpack.



Tip: Use the jetpack to slide up walls and find secret passages!



Vampire Sam




Vampire Sam can transform into a bat and fly short distances.

Hold **down** and push **fire** to transform Vampire Sam into a bat.



While Vampire Sam is a bat:

Use **left** or **right** to make Vampire Sam fly in the desired direction.



Push **fire** to make Vampire Sam flap his wings and gain height.



Hold **down** and push **fire** or touch the ground to turn back into human form.



Tip: Vampire Sam's bat flight time is extended should he run into any collectibles!

Usables

There are many useful objects in the game that Sam can interact with:

Doors



Doors connect the various parts of each level; some are sealed, while others are locked and require a key in order to be opened. Watch out for the flashing door—that's the level exit!

Checkpoints



There are several checkpoints dotted throughout each level. Whenever Sam reaches an inactive checkpoint, he will activate it (deactivating all the others). Should Sam lose his life, you can rewind to the last activated checkpoint.

Tip: It may not always be advantageous to activate a checkpoint!

Rocks



Rocks are found in specific locations throughout each level. Sam can pick up and throw rocks to defend himself against his enemies, and they're also handy for opening any chests which Sam encounters on his travels.

Tip: Use Pitcher Sam to throw rocks with greater power and precision!

Chests



Chests contain all manner of goodies including costumes, diamonds, coins, and trophies (and occasionally keys, switches, and trampolines). Sam can open chests by throwing rocks or chests at them, or by using Pirate Sam's cutlass.

Tip: Sam can also use chests against his enemies!

Keys



Keys are typically found in specific locations throughout each level, but on rare occasions, Sam may also find a key hidden inside a chest. Sam can only enter a locked door if he is carrying a key.

Tip: Once you find a key, make sure you hold onto it!

Switches



Some blocks in the level can be toggled on or off by using switches; if the switch is green the blocks are off; if the switch is red, the blocks are solid. Sam can activate a switch by simply jumping on it. Additionally, some switches are portable and can be moved to more useful locations!

Tip: Beware the switches that have a timer and switch back automatically!

Collectibles

In each level, there are 40 diamonds, 10 coins, and 3 trophies for Sam to discover. The more collectibles Sam acquires, the higher the score. Can you get the perfect 100 percent score for every level?



Diamonds



Diamonds are the most common collectible, and are typically found dotted along Sam's path through the level. Each diamond is worth 1 percent of the level score.

Coins



Rarer than diamonds, coins are typically found off the beaten path and usually require Sam to use a particular costume—or explore hidden areas—to reach them. Each coin is worth 3 percent of the level score.

Trophies



Trophies are extremely rare, and are dropped by specific enemies when killed. In order to collect them all, Sam must therefore locate the three trophy ›keepers‹ dotted around each level. Each trophy is worth 10 percent of the level score.

Transportation

Trampolines



Trampolines can be used by Sam to perform extra-high jumps (see Jumping). Like many objects in the game, trampolines are portable and can be moved to more useful locations!

Moving Platforms



There are several types of moving platforms within the game: some follow a specific path, some travel back and forth between two points, some platforms sink as Sam lands (and rise back up when he jumps), and some will fall off the screen when Sam lands on them!

Cannons



Cannons can be used to catapult Sam over long distances. Some of them are fixed, some of them move, and some of them even rotate! Additionally, some cannons require you to push fire at the opportune moment, while others will fire automatically.

Owls



These friendly creatures don't mind Sam jumping on their heads if it helps him to reach otherwise inaccessible areas of the level.

Creatures

Sam will encounter a multitude of weird and wonderful creatures on his journey, for instance:

Roamers



These fellas aren't much of a threat, and can be dispatched with a single jump on their heads. Roamers usually wander aimlessly back and forth, but as Sam gets further into the game, he'll encounter Roamers with new tricks up their sleeves!

Wasps



These aggressive creatures can be found guarding specific places or items of interest. Some hover on the spot, others follow specific paths, and some even shoot their stinging venom at Sam! They can't be jumped on, so a carefully-aimed rock (or chest!) is usually required.

Caterpillars



Don't be fooled, this innocent-looking creature is more dangerous than it appears! Caterpillars require two jumps on their heads, but will become faster and more aggressive after the first hit. Some of them even shoot at Sam!

Frog Boss



This giant beast lies in wait for Sam at the end of the Lowlands. Initially Sam can only avoid the oversized amphibian's attacks, but later on Sam will discover a way to strike back!

Calling It a Day

If you wish to finish your gaming session, please make sure to save your game so you won't lose your progress!

Cartridge Edition: Switch off the C64, then remove the game cartridge from the expansion port of your computer.

Disk Edition: Remove the disk from the disk drive, then switch off the disk drive and the C64.



Credits

Knights of Bytes

Chester Kollschen: Code, Design, Additional Graphics, Sound Effects

Stefan Gutsch: Pixel Art, Level Design, Additional Design, Cover Art

Alex Ney: Soundtrack

Protovision

Tim Jakob Chen-Voos: Physical Production Lead, Distribution

poly.play

Sebastian Bach: Game Manual Design and Layout, Additional Production

Quality Assurance

Andy Roberts: Testing, Proofreading

Melanie Schröder: Testing

Milo Mundt: Testing



Stefan Nowak: Testing

Additional Help and Support

Malte Mundt, Frank Erstling, Daniel Meléndez, Bieno Marti Braitmaier, Jennifer Roberts, and all our supporters on Patreon and PayPal!

A Big Thanks

to **Lasse Öörni** for his awesome »Ninja Tracker«, and **Magnus Lind** for the great »Exomizer«.





SAM'S Journey

Are you ready for a brand-new epic C64 platform adventure?
Accompany Sam on his fantastic journey through a huge and colorful world!
Three overworld maps with a total of 30 levels are waiting to be explored!
Discover secret passages, find hidden items and fight strange creatures!
And don't miss the six special power suits that completely change Sam's
appearance and give him additional skills!

A Game By

**Chester Kollschen
Stefan Gutsch
Alex Ney**



Knights of Bytes



PROTOVISION